



Title of Change:	2Q2016 Product Discontinuance Notice.
Last Time Buy Date:	22 January 2017
Last Ship Date:	22 July 2017
Contact information:	Contact your local ON Semiconductor Sales Office or <PCN.Support@onsemi.com >
Type of notification:	Customers must notify ON Semiconductor (<PCN.Support@onsemi.com >) in writing within 90 days of receipt of this notification if they consider the discontinued product to be "Sole Source." ON Semiconductor and the customer may negotiate an appropriate End-of-Life.

Description and Purpose:

In an attempt to minimize the number and frequency of product discontinuance notices to its customers, ON Semiconductor is publishing this quarterly product discontinuance notification.

Some of the devices contained in this notice may be part of a product portfolio renewal process or a manufacturing facility closure. ON Semiconductor continually monitors worldwide sales and billings activities on all the products offered to its customers.

The activity for the products on the attached device list has declined to a level that warrants the discontinuance of these products or the manufacturing facility has been announced for a closure. Some devices may have an alternate standard device or a suggested replacement as an alternative solution.

ON Semiconductor wishes to promptly inform our customer of our intent to exit this small portion of our overall portfolio so that you may plan appropriately and effectively for replacement devices.

ON Semiconductor has provided a list of replacement devices, where available, to aid in this process.

For those devices that have no recommended replacement identified, ON Semiconductor has partnered with Rochester Electronics who will carry any remaining device inventory as well as mask sets, etc. to potentially allow for a continued source after ON Semiconductor has completed its business process.

PLEASE NOTE: ON Semiconductor may implement minimum order quantities or dollar amounts based on inventories available. Also, Devices on this Product Discontinuance become NCNR (Non-Cancelable, Non-Returnable).

For questions or concerns regarding this notification, please contact your local sales office or customer service representative.

Additional contacts are:

Americas:

Tom Siegel (tom.siegel@onsemi.com)

☎ +1 765 868 5022

USA

Japan:

Isao Usuki (isao.usuki@onsemi.com)

☎ +81 3 5817 1060

Japan

Europe:

Andrej Tomasik (andrej.tomasik@onsemi.com)

☎ +421 33790 2229

Slovakia

Asia Pacific:

Stephen Ng (stephen.ng@onsemi.com)

☎ +852 2689 0209

China



NOTE: UPON PUBLICATION OF THIS DISCONTINUANCE NOTICE, ON SEMICONDUCTOR ALLOWS SIX (6) MONTHS FROM THE NOTICE DATE TO PLACE FINAL LIFETIME PURCHASE ORDERS. ACCEPTANCE IS SUBJECT TO REASONABLE ORDER QUANTITIES, PRODUCT AVAILABILITY AND ALL OTHER APPLICABLE TERMS AND CONDITIONS

NOTE: TO ALLOW AN ORDERLY EXIT FROM THE MARKET, PRODUCT SHALL NOT BE DELIVERED AFTER TWELVE (12) MONTHS BEYOND THE ANNOUNCEMENT DATE.

List of affected Parts: *See attachment*

To access file attachments on pdf copy of PDN, please be guided by the steps below:

- 1. Download pdf copy of the PDN to your computer*
- 2. Open the downloaded pdf copy of the PDN*
- 3. Click on the paper clip icon available on the menu provided in the left/bottom portion of the screen to reveal the Attachment field*
- 4. Then click on the attached file/s*

MPN	CPN	Company Name
LB1848MGEVB		DIGI-KEY
NCP5392PMNR2G		DIGI-KEY
NCP3218MNR2G		DIGI-KEY
LV8400V-MPB-E		DIGI-KEY
NGTB15N120IHLWG		DIGI-KEY
NCP432FCT2GEVB		DIGI-KEY
NGTB20N120IHLWG		DIGI-KEY
NCP437FCT2GEVB		DIGI-KEY
LB1938TGEVB		DIGI-KEY
LB1938FA-AH		DIGI-KEY
NCP436FCT2GEVB		DIGI-KEY
LV8548MGEVB		DIGI-KEY
LB1973MGEVB		DIGI-KEY
NGTB30N60FLWG		DIGI-KEY
LB1930MGEVB		DIGI-KEY
NLAS4501DFT2G		DIGI-KEY
NCN9252MUTAG		DIGI-KEY
LV5061VGEVB		DIGI-KEY
NCP434FCT2GEVB		DIGI-KEY
LV8549MGEVB		DIGI-KEY
NLAS4501DTT1G		DIGI-KEY
NCN3411MTTWG		DIGI-KEY
NCN3612BMTTWG		DIGI-KEY
NS3L500MTTWG		DIGI-KEY
NLAS44599MNR2G		DIGI-KEY
LV8741V-MPB-E		DIGI-KEY
MC100EP131MNR4G		DIGI-KEY
LB1846MC-ZH		DIGI-KEY
NLAS4501DTT1G		DIGI-KEY
MC100EL29DWG		DIGI-KEY
MC100EP101FAR2G		DIGI-KEY
MC10EP16DR2G		DIGI-KEY
LC75822ED-E		DIGI-KEY
MC10EP195MNG		DIGI-KEY
ADT7461ARMZ-2R		DIGI-KEY
LB11861H-MPB-E		DIGI-KEY
LC750241E-E		DIGI-KEY
MC10EP101MNR4G		DIGI-KEY
LV8740V-MPB-E		DIGI-KEY
LC75805PEH-3H		DIGI-KEY
MC10H646FNG		DIGI-KEY
MC10EP16VADR2G		DIGI-KEY
ADM1034ARQZ-REEL		DIGI-KEY
MC100EP101MNR4G		DIGI-KEY
MC100LVEL12DG		DIGI-KEY
LV8011V-MPB-E		DIGI-KEY
MC100EL31DR2G		DIGI-KEY
LV8800V-MPB-E		DIGI-KEY
NLAS5213BMUTAG		DIGI-KEY
LC75834WHS-E		DIGI-KEY
MC10EP105MNR4G		DIGI-KEY

LB1937T-MPB-E	DIGI-KEY
LC75833WHS-E	DIGI-KEY
MC10EP17DTR2G	DIGI-KEY
NLAS4501DFT2G	DIGI-KEY
MC10EP58DTG	DIGI-KEY
LB1938FA-AH	DIGI-KEY
NLAS3799BLMNR2G	DIGI-KEY
MC10EP142MNR4G	DIGI-KEY
LV8013T-A-MPB-E	DIGI-KEY
MC10EP116FAR2G	DIGI-KEY
MC100EL30DWG	DIGI-KEY
LC75810TS-8725-E	DIGI-KEY
MC10SX1190DTR2G	DIGI-KEY
LB1867M-MPB-E	DIGI-KEY
LV8413GP-TE-L-E	DIGI-KEY
MC100LVEL12DTG	DIGI-KEY
MC10EP29MNTXG	DIGI-KEY
NLAS3799BMNR2G	DIGI-KEY
LC75824W-E	DIGI-KEY
MC100EP445MNR4G	DIGI-KEY
MC100H642FNG	DIGI-KEY
MC100EP17DTR2G	DIGI-KEY
LC75874WHS-SH-E	DIGI-KEY
LB11948T-MPB-E	DIGI-KEY
LC75839PWS-H	DIGI-KEY
MC10EP446FAR2G	DIGI-KEY
LNLASB3157DFT2G	DIGI-KEY
LA6584M-MPB-H	DIGI-KEY
MC100LVEL59DWG	DIGI-KEY
LV8860PV-MPB-H	DIGI-KEY
NGTB50N60FLWG	DIGI-KEY
LC75838WS-E	DIGI-KEY
MC100EP16VSDG	DIGI-KEY
LB11876-MPB-E	DIGI-KEY
MC10EL12DTG	DIGI-KEY
LC75879PTS-T-H	DIGI-KEY
MC100E164FNR2G	DIGI-KEY
MC10EP31DTR2G	DIGI-KEY
MC100EP16VTDTR2G	DIGI-KEY
NDT02N60ZT3G	DIGI-KEY
MC10EP52MNR4G	DIGI-KEY
LA4450F-E	DIGI-KEY
MC10EP131MNR4G	DIGI-KEY
MC100E210FNG	DIGI-KEY
MC10EP58DTR2G	DIGI-KEY
LV8809J-ZH	DIGI-KEY
LC75822EHS-T-E	DIGI-KEY
LC75822EHS-E	DIGI-KEY
MC100EP196BFAR2G	DIGI-KEY
LV8800V-MPB-H	DIGI-KEY
NCP5338MNR2G	DIGI-KEY
MC10E136FNG	DIGI-KEY

MC10EP29DTR2G	DIGI-KEY
MC10EP131FAR2G	DIGI-KEY
MC10EP101FAR2G	DIGI-KEY
NLAST44599MNG	DIGI-KEY
MC10EP31MNR4G	DIGI-KEY
NLAS3699BMN1R2G	DIGI-KEY
MC100EP16VSDTR2G	DIGI-KEY
LC75897PWS-T-E	DIGI-KEY
MC10EP17MNG	DIGI-KEY
LC75700T-MPB-E	DIGI-KEY
MC100EP16VBDR2G	DIGI-KEY
NGTB20N120IHLWG	DIGI-KEY
MC10E142FNG	DIGI-KEY
LC75839PWS-T-H	DIGI-KEY
MC10EP139DWR2G	DIGI-KEY
LC75811W-8715HS-E	DIGI-KEY
LC75700TS-MPB-E	DIGI-KEY
LV8019V-MPB-E	DIGI-KEY
LC75725E-E	DIGI-KEY
LV8810J-ZH	DIGI-KEY
MC10EP58DG	DIGI-KEY
MC10LVEP16DR2G	DIGI-KEY
LB11988V-MPB-E	DIGI-KEY
MC100EP445FAR2G	DIGI-KEY
LC75809PTS-T-H	DIGI-KEY
ADT7485AARMZ-R	DIGI-KEY
NS3L500MTTWG	DIGI-KEY
STK621-015B1-E	DIGI-KEY
NCP3218MNR2G	DIGI-KEY
NCP436FCT2G	DIGI-KEY
LV8413GP-E	DIGI-KEY
MC100E211FNG	DIGI-KEY
MC100EP139DWR2G	DIGI-KEY
STK621-520A-E	DIGI-KEY
NCP434FCT2G	DIGI-KEY
MC10EP105MNG	DIGI-KEY
LV8771VH-MPB-H	DIGI-KEY
MC100EP31DR2G	DIGI-KEY
LC75836W-TBM-E	DIGI-KEY
LC75829PWS-T-H	DIGI-KEY
MC100EP35DR2G	DIGI-KEY
NLAS44599DTG	DIGI-KEY
LV8804FV-MPB-H	DIGI-KEY
LA4814JA-ZE	DIGI-KEY
MC100EPT622MNR4G	DIGI-KEY
MC10EP195FAR2G	DIGI-KEY
MC100EP16VCMNR4G	DIGI-KEY
MC10EP16TDTG	DIGI-KEY
MC10EP445FAR2G	DIGI-KEY
MC10EP35DR2G	DIGI-KEY
MC10EP16TDR2G	DIGI-KEY
MC100EP105MNR4G	DIGI-KEY

MC100EL13DWR2G	DIGI-KEY
NLAST44599DTR2G	DIGI-KEY
NLAS9431MTR2G	DIGI-KEY
MC100E158FNG	DIGI-KEY
LB11961V-MPB-E	DIGI-KEY
LA6584JA-ZH	DIGI-KEY
MC100EP195MNR4G	DIGI-KEY
MC100EP196BMNR4G	DIGI-KEY
MC10EP35DG	DIGI-KEY
MC10EP16VADTR2G	DIGI-KEY
LB11967V-MPB-E	DIGI-KEY
MC10EP451MNR4G	DIGI-KEY
NCP437FCT2G	DIGI-KEY
MC100EP58DTR2G	DIGI-KEY
NGTB30N60FLWG	DIGI-KEY
LA6502-MPB-E	DIGI-KEY
STK621-521-E	DIGI-KEY
NCP5623AMUTBG	DIGI-KEY
LE25LB2562CT-TE-F-H	DIGI-KEY
LC75879PTS-H	DIGI-KEY
MC100EP16VSDR2G	DIGI-KEY
MC10EP16TMNR4G	DIGI-KEY
MC100E404FNG	DIGI-KEY
MC100EL29DWR2G	DIGI-KEY
NCV8503PW50R2G	DIGI-KEY
MC10EP01DTR2G	DIGI-KEY
NLAST9431MTR2G	DIGI-KEY
NLAS3799MNR2G	DIGI-KEY
MC10EL12DG	DIGI-KEY
LV8400V-MPB-E	DIGI-KEY
MC10E211FNG	DIGI-KEY
LC75854WHS-E	DIGI-KEY
MC10EPT20MNR4G	DIGI-KEY
MC10SX1130DG	DIGI-KEY
STK554U364A-E	DIGI-KEY
MC10E446FNG	DIGI-KEY
NLAS44599DTR2G	DIGI-KEY
NCP5392PMNR2G	DIGI-KEY
LB11961RM-MPB-E	DIGI-KEY
MC10EP33DTR2G	DIGI-KEY
MC10EP57MNTXG	DIGI-KEY
MC10H103FNG	DIGI-KEY
STK621-717-E	DIGI-KEY
MC100E310FNR2G	DIGI-KEY
LC75833EHS-E	DIGI-KEY
MC10EP16TDG	DIGI-KEY
STK628-131B-E	DIGI-KEY
MC10EP142FAR2G	DIGI-KEY
LC75835W-E	DIGI-KEY
NLAS3699MN1R2G	DIGI-KEY
MC10SX1130DR2G	DIGI-KEY
NLAS3799LMNR2G	DIGI-KEY

MC100EP116MNR4G	DIGI-KEY
MC10EP16VADG	DIGI-KEY
LV8291T-MPB-E	DIGI-KEY
MC100EP11DR2GH	DIGI-KEY
MC10EP35DTR2G	DIGI-KEY
LB1980H-MPB-E	DIGI-KEY
MC100EP139MNTXG	DIGI-KEY
LB11852RV-MPB-H	DIGI-KEY
MC100EP01DR2G	DIGI-KEY
MC100EP16VTDR2G	DIGI-KEY
LB11988HR-MPB-E	DIGI-KEY
MC100EP33DR2G	DIGI-KEY
MC10H158PG	DIGI-KEY
LC75827E-E	DIGI-KEY
MC100EP17DWR2G	DIGI-KEY
MC100E143FNG	DIGI-KEY
STK760-213-E	DIGI-KEY
LC75725EHS-E	DIGI-KEY
LV8133JA-ZH	DIGI-KEY
MC10EP35DTG	DIGI-KEY
MC10EP31DR2G	DIGI-KEY
LB1935FA-AH	DIGI-KEY
MC100LVE210FNG	DIGI-KEY
NGTB15N120IHLWG	DIGI-KEY
MC100EP35MNR4G	DIGI-KEY
NCV866710D250R2G	DIGI-KEY
NCN3612BMTTWG	DIGI-KEY
MC10EP101MNG	DIGI-KEY
LB11685VH-MPB-H	DIGI-KEY
MC10H176PG	DIGI-KEY
LA4537MC-ZH	DIGI-KEY
LC75024E-E	DIGI-KEY
MC10EP01DR2G	DIGI-KEY
LV8850GA-ZH	DIGI-KEY
MC100EL14DWG	DIGI-KEY
LC75829PE-H	DIGI-KEY
MC100EP16VTMNR4G	DIGI-KEY
MC10E157FNG	DIGI-KEY
MC100E136FNG	DIGI-KEY
LC75841PE-H	DIGI-KEY
LE25FU206AMB-TLM-H	DIGI-KEY
LC75814V-MPB-E	DIGI-KEY
NLAST4501DTT1G	DIGI-KEY
MC100EP116MNG	DIGI-KEY
NLAST44599MNR2G	DIGI-KEY
LV8136V-MPB-H	DIGI-KEY
LC75833JE-E	DIGI-KEY
LV8018W-MPB-E	DIGI-KEY
NDT02N60ZT1G	DIGI-KEY
MC10EP52DR2G	DIGI-KEY
MC100EP01DTR2G	DIGI-KEY
MC10E158FNG	DIGI-KEY

NLAS3799BMUR2G	DIGI-KEY
MC10E142FNR2G	DIGI-KEY
LB1867M-MPB-H	DIGI-KEY
NCN3411MTTWG	DIGI-KEY
MC100EP16VTDG	DIGI-KEY
MC10EP451FAR2G	DIGI-KEY
STK760-211-E	DIGI-KEY
LV8805SV-MPB-H	DIGI-KEY
LB1933M-MPB-E	DIGI-KEY
NCP432FCT2G	DIGI-KEY
MC10H605FNG	DIGI-KEY
MC100EP57MNTXG	DIGI-KEY
MC100LVEP05DG	DIGI-KEY
STK581U3C2A-E	DIGI-KEY
LV8401V-MPB-E	DIGI-KEY
MC10EP05DTR2G	DIGI-KEY
STK621-140C	DIGI-KEY
NCP5395GMNR2G	DIGI-KEY
MC100EP16TDR2G	DIGI-KEY
NLAS5213BUSG	DIGI-KEY
MC100EP16FDTR2G	DIGI-KEY
MC10EP58DR2G	DIGI-KEY
MC10EP90DTR2G	DIGI-KEY
LC75814VS-MPB-E	DIGI-KEY
LC75821EHS-E	DIGI-KEY
MC100E457FNG	DIGI-KEY
MC10EP446MNR4G	DIGI-KEY
LA6584M-MPB-E	DIGI-KEY
MC10EP56MNTXG	DIGI-KEY
MC10EP17DWR2G	DIGI-KEY
MC10EP17MNTXG	DIGI-KEY
MC10EP131MNG	DIGI-KEY
MC100EP142MNR4G	DIGI-KEY
NLAST44599DTG	DIGI-KEY
MC10EP16VAMNR4G	DIGI-KEY
LB11861H-MPB-H	DIGI-KEY
NCV8502PDW33R2G	DIGI-KEY
LC87F57C8AU-DIP-E	DIGI-KEY
LB11861JA-ZH	DIGI-KEY
MC100EL12DTG	DIGI-KEY
MC100EP16TMNR4G	DIGI-KEY
LA4628L-E	DIGI-KEY
MC10EP446MNG	DIGI-KEY
NCN9252MUTAG	DIGI-KEY
MC100EP446FAR2G	DIGI-KEY
STK621-712-E	DIGI-KEY
LC75725E-TLA-E	DIGI-KEY
MC10EP33MNR4G	DIGI-KEY
MC100EP16VCDR2G	DIGI-KEY
MC100EP446MNR4G	DIGI-KEY
CM1230-04CP	DIGI-KEY
MC100EL12DG	DIGI-KEY

LB1923M-MPB-E	DIGI-KEY
LC75835W-TBM-E	DIGI-KEY
MC100EP16FDR2G	DIGI-KEY
MC100EP16VADR2G	DIGI-KEY
LV8019LP-MPB-E	DIGI-KEY
MC10EP08DTR2G	DIGI-KEY
ADP3211MNR2G	DIGI-KEY
NLAS44599MNG	DIGI-KEY
MC100EP210SFATWG	DIGI-KEY
STK621-034B1-E	DIGI-KEY
LC75348M-TLM-E	DIGI-KEY
LC75827WS-SH-E	DIGI-KEY
MC10EP89MNR4G	DIGI-KEY
LB1843V-MPB-E	DIGI-KEY
LV8549MGEVB	DIGI-KEY